Utilities

```
from matplotlib import pyplot as plt
import numpy as np
import cv2
# Show result in seperate window
def show result(img):
    cv2.imshow('image',img)
    cv2.waitKey(0)
    cv2.destroyAllWindows()
# Saving video utilities
import glob
def process video(path, func, dst_folder):
    cap = cv2.VideoCapture(path)
    i = 0
    while(cap.isOpened()):
        # vid_capture.read() methods returns a tuple, first element is
a bool
        # and the second is frame
        ret, frame = cap.read()
        if ret == True:
            f = frame.copy()
            res = func(f)
            # Save frame into image file
            s = ""
            if(i < 10):
                s = "00"
            elif(i < 100):
                s = "0"
            cv2.imwrite('res\\' + dst_folder + '\\kang_'+ s +str(i)
+'.jpg',res)
            i = i + 1
            # displaying the video
            #cv2.imshow("Processed Video", res)
            if cv2.waitKey(1) & 0xFF == ord('q'):
                break
        else:
            break
    cap.release()
    cv2.destroyAllWindows()
def save img2video(dst folder, name = 'output.mp4'):
    # Save images into a video file
```

```
imq array = []
    for filename in glob.glob('res\\' + dst folder + '\\kang*.jpg'):
        img = cv2.imread(filename)
        height, width, layers = img.shape
        size = (width,height)
        img array.append(img)
    out = cv2.VideoWriter(name, cv2.VideoWriter fourcc(*'DIVX'), 30,
size)
    for i in range(len(img_array)):
        out.write(img array[i])
    out.release()
def save clips(path, dst folder, idxs):
    cap = cv2.VideoCapture(path)
    i = 0
    it = iter(idxs)
    val = next(it)
    while(cap.isOpened()):
        # vid capture.read() methods returns a tuple, first element is
a bool
        # and the second is frame
        ret, frame = cap.read()
        i = i + 1
        if ret == True:
            if i == val:
                cv2.imwrite(dst folder + '\\clip ' +str(i)
+'.png',frame)
                try:
                    val = next(it)
                except:
                    break
        else:
            break
    cap.release()
    cv2.destroyAllWindows()
# save clips('video.mp4', 'tmp', [793, 794])
def merge imgs(img1, img2):
    h = np.maximum(img1.shape[0], img2.shape[0])
    w = img1.shape[1] + img2.shape[1]
    res = np.zeros((h, w, 3), dtype=np.uint8)
    res[0:img1.shape[0], 0:img1.shape[1],:] = img1
    res[0:img2.shape[0], img1.shape[1]:, :] = img2
    return res
```

```
ORB tracking
master img = cv2.imread('marker.jpg')
orb = \overline{\text{cv2.0RB}} create(2000, 1.2, 13)
kp master, des master = orb.detectAndCompute(master img, None)
def orb process(secondary img):
    kp secondary, des secondary =
orb.detectAndCompute(secondary img, None)
    # Initialize the Matcher for matching the keypoints and then match
the keypoints
    matcher = cv2.BFMatcher(cv2.NORM HAMMING, crossCheck=True)
    matches = matcher.match(des master,des secondary)
    selected = []
    for m in matches:
        if m.distance < 4000:</pre>
            selected.append(m)
    if len(selected) > 10:
        # Prepare source and destination points for homography search
        dst pts = np.float32([kp master[m.queryIdx].pt for m in
selected]).reshape(-1, 1, 2)
        src pts = np.float32([kp secondary[m.trainIdx].pt for m in
selected]).reshape(-1, 1, 2)
        # Find homography (h matrix - homography matrix)
        h matrix, mask = cv2.findHomography(dst pts, src pts,
cv2.RANSAC, 3.0)
        #dst = cv2.perspectiveTransform(dst pts, h matrix)
        img = master img
        h inv = np.linalg.inv(h matrix)
        warped = cv2.warpPerspective(secondary img, h inv,
dsize=(img.shape[1], img.shape[0]), flags=cv2.INTER LINEAR)
        # draw rectangle
        h,w,d = master img.shape
        pts = np.float32([[0,0],[0,h-1],[w-1,h-1],[w-1,h-1])
1,0] ]).reshape(-1,1,2)
        dst = cv2.perspectiveTransform(pts, h matrix)
        homography = cv2.polylines(secondary img, [np.int32(dst)],
True, (255, 0, 0), 3)
        res img = merge imgs(warped, homography)
    else:
        res img = merge imgs(master img, secondary img)
        r, c, = master img.shape
        res img[0:r, 0:c] = 0
    return res img
```

```
def orb process flann(secondary img):
    kp secondary, des secondary =
orb.detectAndCompute(secondary_img, None)
    index_params = dict(algorithm=6,
                         table number=6,
                         key size=12,
                         multi probe level=2)
    search params = {}
    flann = cv2.FlannBasedMatcher(index params, search params)
    matches = flann.knnMatch(des master, des secondary, k=2)
    # As per Lowe's ratio test to filter good matches
    selected = []
    for m, n in matches:
        if m.distance < 0.75 * n.distance:</pre>
            selected.append(m)
    if len(selected) > 10:
        # Prepare source and destination points for homography search
        dst pts = np.float32([kp master[m.queryIdx].pt for m in
selected]).reshape(-1, 1, 2)
        src_pts = np.float32([kp secondary[m.trainIdx].pt for m in
selected]).reshape(-1, 1, 2)
        # Find homography (h matrix - homography matrix)
        h matrix, mask = cv2.findHomography(dst pts, src pts,
cv2.RANSAC, 3.0)
        #dst = cv2.perspectiveTransform(dst pts, h matrix)
        img = master img
        h inv = np.linalq.inv(h matrix)
        warped = cv2.warpPerspective(secondary img, h inv,
dsize=(img.shape[1], img.shape[0]), flags=cv2.INTER LINEAR)
        # draw rectangle
        h,w,d = master img.shape
        pts = np.float32([ [0,0],[0,h-1],[w-1,h-1],[w-1,h-1])
1,0] ]).reshape(-1,1,2)
        dst = cv2.perspectiveTransform(pts, h matrix)
        homography = cv2.polylines(secondary \overline{i}mq, [np.int32(dst)],
True, (255, 0, 0), 3)
        res img = merge imgs(warped, homography)
    else:
        res_img = merge_imgs(master_img, secondary_img)
        r, c, _ = master_img.shape
        res_img[0:r, 0:c\overline{1}=0
    return res img
```

```
# check for one image
img = cv2.imread('tmp\clip 44.jpg')
res = orb_process_flann(img)
plt.imshow(res)
<matplotlib.image.AxesImage at 0x1df19453370>
             HACHEZ
  200
  400
  600 -
           250
                                    1250
                                           1500
      0
                  500
                        750
                              1000
                                                 1750
                                                        2000
process video('video.mp4', orb process flann, 'orb flann')
save img2video('orb flann', 'orb flann.mp4')
Lucas Kanade
master img = cv2.imread('marker.jpg')
orb = cv2.0RB create(2000, 1.2, 13)
kp master, des master = orb.detectAndCompute(master img, None)
def orb process flann(img):
    secondary img = img.copy()
    kp_secondary, des_secondary =
orb.detectAndCompute(secondary img, None)
    index_params = dict(algorithm=6,
                        table number=6.
                        key_size=12,
                        multi probe level=2)
    search params = {}
    flann = cv2.FlannBasedMatcher(index params, search params)
    matches = flann.knnMatch(des master, des secondary, k=2)
    # As per Lowe's ratio test to filter good matches
    selected = []
    for m, n in matches:
        if m.distance < 0.75 * n.distance:</pre>
            selected.append(m)
    dst = None
```

```
if len(selected) > 10:
        # Prepare source and destination points for homography search
        dst_pts = np.float32([kp_master[m.queryIdx].pt for m in
selected]).reshape(-1, 1, 2)
        src pts = np.float32([kp secondary[m.trainIdx].pt for m in
selected]).reshape(-1, 1, 2)
        # Find homography (h matrix - homography matrix)
        h matrix, mask = cv2.findHomography(dst pts, src pts,
cv2.RANSA\overline{C}, 3.0)
        # inliers
        matchesMask = mask.ravel()
        inliers = src pts[mask]
        #dst = cv2.perspectiveTransform(dst pts, h matrix)
        imq = master imq
        h inv = np.linalg.inv(h matrix)
        #warped = cv2.warpPerspective(secondary img, h inv,
dsize=(img.shape[1], img.shape[0]), flags=cv2.INTER LINEAR)
        # draw rectangle
        h,w,d = master_img.shape
        pts = np.float32([[0,0],[0,h-1],[w-1,h-1],[w-1,h-1])
1,0] ]).reshape(-1,1,2)
        dst = cv2.perspectiveTransform(pts, h matrix)
        homography = cv2.polylines(secondary_img, [np.int32(dst)],
True, (255, 0, 0), 3)
        res img = homography
        #res img = merge imgs(warped, homography)
    else:
        res img = merge imgs(master img, secondary img)
        r, c, _ = master_img.shape
        res img[0:r, 0:c] = 0
    return res img, dst
# check for one image
img = cv2.imread('tmp\clip 44.jpg')
res, dst = orb process flann(img)
plt.imshow(res)
<matplotlib.image.AxesImage at 0x1df0002c160>
```

```
0
                              HACHEZ
  100
  200
  300
  400
  500
  600
  700
             200
                     400
                              600
                                      800
                                              1000
                                                      1200
      0
from matplotlib import pyplot as plt
import numpy as np
import cv2
MIN POINT TO TRACK = 4
def orb_process_flann_step(frame, old area):
    good point to track = None
    new area = 0
    frame, p0 = orb_process_flann(frame)
    if not(p0 is None):
        if(len(p0) >= MIN POINT TO TRACK):
            p = cv2.convexHull(p0)
            new area = cv2.contourArea(p)
            if(old area == 0) or ((new area > 0.5 * \text{ old area}) and
(new area < 2 * old area)): # area is ok
                good_point_to_track = p0
    return frame, new_area, good_point_to_track
def lucas kanade method(video path, dst folder):
    # Read the video
    cap = cv2.VideoCapture(video path)
    # Parameters for Lucas Kanade optical flow
    lk params = dict(
        winSize=(35, 35),
        \max Level=2,
        criteria=(cv2.TERM CRITERIA EPS | cv2.TERM CRITERIA COUNT, 10,
0.03),
    # Create random colors
```

```
color = np.random.randint(0, 255, (1000, 3))
    good_point_to_track = None
    old area = 0
    i = 0
    while(cap.isOpened()):
        # Read new frame
        ret, frame = cap.read()
        if ret == True:
            curr_gray = cv2.cvtColor(frame, cv2.COLOR BGR2GRAY)
            new area = 0
            if(good_point_to_track is None):
                frame, new_area, good_point_to_track =
orb_process_flann_step(frame, old_area)
            else:
                p0 = good_point_to_track.reshape(-1, 1, 2)
                # Calculate Optical Flow
                p1, st, err = cv2.calcOpticalFlowPyrLK(old gray,
curr_gray, p0, None, **lk_params)
                # Select good points
                good new = p1[st == 1]
                good old = p0[st == 1]
                is track found = False
                if(len(good_new) >= MIN_POINT_TO_TRACK):
                    p = cv2.convexHull(p1)
                    new area = cv2.contourArea(p)
                    if(old_area == 0) or ((new_area > 0.5 * old_area)
and (new_area < 2 * old_area)): # area is ok</pre>
                        is_track_found = True
                        good_point_to_track = good_new
                        # Draw rectangle & tracks
                        frame = cv2.polylines(frame, [np.int32(p)],
True, (255, 0, 0), 3)
                        # Draw the tracks
                        for j, (new, old) in enumerate(zip(good new,
good old)):
                            a, b = new.ravel()
                            c, d = old.ravel()
                            a = int(a); b = int(b); c = int(c); d =
int(d)
                            \#mask = cv2.line(mask, (a, b), (c, d),
color[i].tolist(), 2)
                            frame = cv2.circle(frame, (a, b), 5,
color[j].tolist(), -1)
```

```
if not is_track_found:
                    frame, new area, good point to track =
orb_process_flann_step(frame, old_area)
            # Update the previous frame and previous points
            old gray = curr gray.copy()
            old area = new area
            # Save frame into image file
            s = ""
            if(i < 10):
                s = "00"
            elif(i < 100):
                s = "0"
            cv2.imwrite('res\\' + dst folder + '\\kang '+ s +str(i)
+'.jpg',frame)
            i = i + 1
            if(i %100 == 0):
                print(i)
            #cv2.imshow("frame", frame)
            # Press Q on keyboard to exit
            #if cv2.waitKey(25) \& 0xFF == ord('q'):
            # break
        else:
            break
    cap.release()
    # Closes all the frames
    cv2.destroyAllWindows()
lucas_kanade_method('video.mp4', 'optical_flow')
100
200
300
400
500
600
700
800
900
save img2video('optical flow', 'optical flow.mp4')
```